

REPAIR

The end user must not repair or modify any component associated with this device without written permission from TMAC.

If repair is required contact TMAC.

TMAC

45 Enterprise St Cleveland

QLD 4163 Australia

Tel: (+61) 07 3826 6000

<http://www.tmacgroup.com.au/>

DEFECTS / WARRANTY

DEFECTS

Goods are warranted to be free from defects. Provided they have been used strictly as recommended and subjected only to fair wear and tear, Goods (including parts within) which are found to be defective within 90 days after delivery to the Buyer will be repaired or replaced at the option of the Seller and at its expense. Repair or replacement by the Seller is the exclusive remedies of the Buyer.

WARRANTY

To the maximum extent permitted by law, the Seller makes no warranties, either express or implied, as to merchantability, fitness for purpose or otherwise with respect to the Goods other than in paragraph above and as required by statute. The Seller is not liable for any prospective profits or special, indirect or consequential damages or any general loss or damage, or for any expense resulting from use by the Buyer or others of defective Goods. The Seller's liability is limited to no more than the sale price of the Goods plus replacement delivery charges. Prior authority for the return of goods is required by the seller.

Please contact the seller by email sales@tmacgroup.com.au, phone 07 3826 6000 or fax 07 3826 6066 for claims related to defective / warranty of goods provided.

FOR THE FULL TERMS AND CONDITIONS PLEASE REFER TO TMAC "STANDARD TERMS OF TRADE"



Universal Lifter Pole or Crossarm User Guide



ACTIVE INNOVATION



THIS PAGE HAS BEEN LEFT INTENTIONALLY BLANK

STORAGE

When not in use, the the Universal Lifter and associated Brackets should be secured to the vehicle to avoid unnecessary movement, which could impair the integrity of the Lifter.



ROUTINE MAINTENANCE & INSPECTIONS

GENERAL



Every 6 months and irrespective of use, the Lifter must be inspected.

- Clean off any excessive dirt with mild soapy water, rinse and allow to dry;
- Check the Brackets and Arm for the following defects: Cracks, deformation, permanent bending or excessive corrosion and deterioration of the webbing strap;
- Check all welds;
- Check the ratchet , straps, thumb screws, hooks and pins for damage or distortion;
- Check the nylon bushes for damage or wear;
- Check webbing straps for wear and or abrasion and replace as necessary. Abraded straps may not be used in any circumstances.




5. Attach the hauling line to the top of the lifting arm and haul into position.
6. Insert the Arm into the receptacle provided on the Bracket and tighten the Thumb Screw provided to secure the Arm against turning in its receptacle.
7. Remove the hauling rope from the lifting arm.
8. Check that the Bracket is secured to the cross arm safely and that it is in a position where it can support the required load without dangerous movement.

CHANGING THE HEAD HEIGHT



Hazard Identification – Make sure the locating socket headed bolt is nestled in its locator on the bottom of the lifting head before evenly tightening the support brackets.

1. You have two (2) lifting heights for the eye bolt. The lower level height is 985mm from the base of the lifting arm whilst the upper level is 1350mm from the base.
2. Remove all four (4) socket headed bolts on the Lifting Head holding it to the aluminium arm.
3. Move the Lifting Head to the new height; ensure the locating socket head bolt is located into the bottom slot on the Lifting Head.
4. Replace all four (4) socket headed bolt and tighten evenly.
5. Ensure the locating socket headed bolt is in the bottom slot of the Lifting Head as this will prevent any slippage during load operations.



CONTENTS

CONTENTS	3
BEFORE YOU START	4
GENERAL PRECAUTIONS	4
QUALIFIED PERSON	4
SAFETY SYMBOLS USED IN THE GUIDE	4
GENERAL INFORMATION	5
DESCRIPTION	5
PRODUCT INFORMATION	5
1 Pole mounted version	5
2 Cross arm mounted version	6
2.1 Horizontal Crossarm	6
2.2 Vertical Crossarm	6
SAFETY	7
WORKING LOAD LIMITS	7
Pole or cross arm mounted	7
Before Use	7
OPERATION	7
WEIGHT	7
CARRYING AND HAULING THE UNIVERSAL LIFTER TO POSITION	8
ATTACHING THE LIFTER TO THE POLE	8
ATTACHING THE LIFTER TO EITHER HORIZONTAL OR VERTICAL CROSS ARM	9
CHANGING THE HEAD HEIGHT	10
STORAGE	11
ROUTINE MAINTENANCE & INSPECTIONS	11
GENERAL	11
REPAIR	12
DEFECTS / WARRANTY	12
DEFECTS	12
WARRANTY	12

BEFORE YOU START

GENERAL PRECAUTIONS



Read and understand this guide before operating this equipment.

The TMAC Universal Lifter is to be used only by qualified personnel and must be used in conjunction with the user's own working and safety procedures, without compromising the integrity of the TMAC product supplied.

Follow all safety instructions contained within this guide.

QUALIFIED PERSON

A qualified person is one who is familiar with the installation, construction, operation or maintenance of the equipment and the hazards involved. In addition this person is competent, trained and authorized to undertake the work involved in accordance with established safety and working procedures.

SAFETY SYMBOLS USED IN THE GUIDE



Mandatory Action - This symbol indicates the action must be taken to avoid a hazard. Any information that follows this symbol must be obeyed to avoid possible harm.



Hazard Identification - This is a general warning sign. It is used to alert the user to potential hazards. Any information that follows this symbol must be obeyed to avoid possible harm.



Prohibition - This symbol indicates an action that must not be taken or must be stopped. Any information that follows this symbol must be obeyed to avoid possible harm.

8.



Insert Lifting Arm Into Socket



ATTACHING THE LIFTER TO EITHER HORIZONTAL OR VERTICAL CROSS ARM



Cross Arm Sizes and Types - The suitable cross arm size range is minimum width 100mm and of sufficient strength to support the load to be applied.

1. Fully inspect the cross-arm to which the Lifter is to be attached to ensure it is capable of supporting the required load.
2. Check to ensure that there are not any sharp edges on the section of the cross arm to which the Lifter is to be attached.
3. Pass the hauling rope through the hollow section of the Cross Arm Bracket and lift into position.




4. Fit the Bracket onto the cross arm, pass the strap around the cross arm and hook the tail end of the strap onto the bolt of the Ratchet Device. Tighten the Ratchet Device to a suitable degree. Repeat with second strap.

CARRYING AND HAULING THE UNIVERSAL LIFTER TO POSITION

NOTE:- : The following pictures are applicable to the two different versions outlined in this guide, namely the Pole Mounted version and the Cross Arm Mounted version.

Both versions of the Lifter may be conveniently carried by the handle of the attached Ratchet.



Carrying the Lifting Brackets

ATTACHING THE LIFTER TO THE POLE



Pole Sizes and Types - The suitable pole diameter range is 240 to 400 mm, in timber, concrete or steel.

1. Fully inspect the pole to which the Lifter is to be attached to ensure it is capable of supporting the required load;
2. Attach the hauling rope to upper of the unused bolts on the side of the Bracket opposite to the Ratchet Device and raise to the required position;
3. Pass first the lower Strap around the pole and hook to the lower bolt on the ratchet device provided for the purpose. Secure firmly to the pole using the Ratchet Device;
4. Remove the hauling rope from the upper bolt, secure the upper Strap and tighten with the Upper Ratchet Device;
5. Adjust both Ratchets as required.
6. Attach the hauling rope to the aluminium Arm and lift into position. Insert into the socket in the Bracket and secure against rotation with the Thumb Screw.
7. Check that the Bracket is secured to the pole safely and that it is in a position where it can support the required load without dangerous movement.

GENERAL INFORMATION

DESCRIPTION

The TMAC Universal Lifter is designed to raise overhead conductors from the existing support in preparation for cross arm or insulator replacement. It is manufactured with a lightweight aluminium frame and webbing securing strap with ratchet tightening. It may be mounted on round wood, steel, or concrete poles or on the cross arm or pole extension arm.



Prohibition – This Universal Lifter is not to be used in association with energised conductors. The device can be used on **de-energised** LV and HV lines **ONLY** providing the WLL is not exceeded.



Hazard Identification – The Lifting Arm has two (2) positions to accommodate various work practices. If changing the lifting head height ensure the lower section is nestled on the locating pin to ensure there is no slippage when under load. Each bracket must be tightened evenly to ensure the security of the lifting head.

PRODUCT INFORMATION

The kit is supplied with two different mounting bases as follows: -

- 1 **Pole mounted version.**



2 Cross arm mounted version

2.1 Horizontal Crossarm.



2.2 Vertical Crossarm



SAFETY

WORKING LOAD LIMITS

Pole or cross arm mounted

- W.L.L: - 250 kg
- Pole Diameters: - 240 mm to 400 mm
- Crossarm:- 100mm X 100mm minimum.

NOTE

W.L.L. constraints may be imposed by the structural integrity of the mounting support be it pole or cross arm. The integrity of such support must be identified prior to use of the Universal Lifter.

Before Use



Each time a Universal Lifter is used, all its components, including the webbing strapping, must be examined for any visible sign of damage or deterioration.



NEVER use the Universal Lifter if any component is damaged, worn or faulty.

OPERATION

WEIGHT



In Pole Mounted Configuration. – The total weight of the Pole mounted Lifter including the Lifting Arm, Bracket, Straps and Ratchet is 12.5kg.

In Cross Arm Mounted configuration. -- The total weight of the Cross Arm mounting Lifter including the Lifting Arm, Bracket, Ratchet and Straps is 11.5kg.

Before carrying the Lifter, ensure the manual handling risks are assessed in accordance with working and safety procedures.